


207610x52A

MOWER HOUSING ASSEMBLY



207610x52A

MOWER HOUSING ASSEMBLY


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	_____	Housing	42	071133	Wheel, Drive
2	*	Engine *	44	071780	Cover, Dust
3	1101653	Pulley, Crankshaft	45	17x137	Washer, Belleville
4	032x64	Pin, Spring	46	17x124	Washer
5	1101625	Cover, Axle (Black)	47	01x144	Bolt
6	1101623	Cover, Belt (Black)	48	672763E701	Blade
7	26x304	Screw	49	1101336	Adapter, Blade
8	1102161	Adjuster, Left Height	50	672602	Adjuster, Right Frt. Height
9	1101639	Spacer, Engine	51	002x16	Bolt, Carriage
10	1101619	Transmission - Note: There are no internal serviceable parts for the transmission.	52	26x221	Screw
			53	025x11	Bolt, Engine
11	043844	Spacer	55	001x45	Bolt
12	164x27	Spring	56	015x79	Nut, Flange
13	015x88	Nut	57	215x17 Z	Rod, Pivot +
14	01x156	Bolt	58	672610	Door, Rear (Gray)
15	028x49	Retainer, Push +	59	166x44	Spring +
16	1102123E701	Bracket, Left Handle	60	671969	Deflector, Rear
17	37x128	Belt	61	1102159	Wheel, Rear
23	011x16	E-Ring	63	1102122E701	Bracket, Right Handle
24	071792	Gear, Pinion	64	1102160	Adjuster, Right Height
25	001x85	Bolt	65	26x245	Screw
26	17x186	Washer	66	014x86	Wingnut
27	672603	Adjuster, Left Frt. Height	68	671926	Bezel
32	043629	Pin, Drive	69	215x18 Z	Pin, Pivot
35	015x68	Nut, Flange	70	671927	Deflector, Chute (Black)
36	15x102	Nut, Hex	71	028x42	Cap, Push
37	017x38	Washer	73	002x81	Bolt, Carriage
38	004x21	Screw	74	071495	Knob
39	043615	Cap, Hub	75	672449	Knob
40	17x169	Washer	--	F-050436L	Instruction Book
41	015x84	Nut, Flange			

* For information on Replacement Parts for this engine contact the manufacturer.

+ These parts are included with Key 58.

207610x52A

HANDLE & BAG ASSEMBLY



KEY NO.	PART NO.	DESCRIPTION
1	1101555E701	Handle, Upper (Black)
2	1102085E701	Handle, Lower (Black)
3	025x14	Bolt
4	1101678	Cable, Drive
5	15x116	Locknut
6	1101183	Cable, Stop
7	1101353	Fastener, Cable
8	672878E701	Engine Stop Lever

KEY NO.	PART NO.	DESCRIPTION
9	1101454	Bracket, Stop Lever
12	002x77	Bolt
13	071294	Knob
16	071530	Guide, Rope
28	071592	Frame, Top
29	672905	Frame Assembly
30	1101117	Bag, Cloth