



POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	417619	HUS VENSTRE	LEFT HOUSING ASSEM.
2	1	417620	LEDNINGSHOLDER	CORD CLAMP ASSEM.
3	1	417621	MOTOR KOMPLET	MOTOR ASSEM.
4	1	417622	LEDNING	VDE CABLE
5	1	417623	JUSTERKNOB	SPEED ADJUSTING KNOB
6	1	417624	GASARM	TRIGGER
7	1	417625	KONTAKT	SWITCH
8	1	417626	HUS HØJRE	RIGHT HOUSING ASSEM.
9	1	417627	SELE	SHOULDER BELT ASSEM.
10	1	417628	HÅNDTAG KOMPLET	ASSISTANT HANDLE ASSEM.
11	1	417629	KNOB	CONVERSION KNOB ASSEM.
12	1	417630	DØR	DOOR
13	1	417631	RØR ØVRE	REAR TUBE ASSEM.
14	1	417632	RØR NEDRE	FRONT TUBE ASSEM.
15	1	417633	MUNDSTYKKE	CREVICE TOOL ASSEM.
16	1	417634	POSE	COLLECTION BAG