REPAIR PARTS MANUAL

39" - 12 H.P. RIDING MOWER

Rød

MODEL 3560-74

WARRANTY



ONE YEAR LIMITED WARRANTY

For one (1) year from date of purchase by the first consumer for residential use (thirty (30) days commercial use), Western International Incorporated warrants that it will replace free of charge, including labor, any original part of any Western International Incorporated product found to be defective by any authorized Service Dealer or the factory, except the battery which is warranted for ninety (90) days from date of purchase.

This warranty does not cover engine, transmission, transaxle or differential (these items are covered by their manufacturer's own warranty). This warranty does not cover parts that have failed due to normal wear or parts that have failed subject to misuse or abuse. Transportation of the unit or part to and from an authorized Service Dealer or the factory is the responsibility of the owner.

A step by step explanation as to what procedure should be followed for this Warranty is:

- 1. If a part becomes defective, contact the store where the unit was purchased for the name and address of the authorized Service Dealer nearest to you.
- If you cannot locate an authorized Service Dealer, write Service Department of Western International Incorporated for the name and address of the authorized Service Dealer in your area or call the Service Department at 1-800-247-7464 (outside Iowa), 1-515-265-3461 (Iowa).
- 3. Return the defective product, along with proof of purchase to such authorized Service Dealer for replacement of any defective part where covered by this warranty.

There is no other express warranty. Implied warranties, including those of merchantibility and fitness for a particular purpose are limited to one (1) year from date of purchase. Liability for incidental or consequential damages are excluded.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

Western International Incorporated

P.O. Box 377

Des Moines, Iowa 50302

UNIT PARTS AND SERVICE

This manual contains repair parts information and instructions for safety. Read the operator's manual carefully and completely so that you will know proper assembly, use and care of your unit. Fill in and mail the registration card packed with the unit. For service other than covered in operator's manual, contact an authorized service dealer. A nationwide parts and service organization has been established to provide locally available parts and service. A list of authorized parts distributors has been included in this manual. When ordering repair parts, always give the following information: 1. The Part Name; 2. The Part Number; 3. The Quantity desired; 4. The Full (eight digit) Model Number of the unit. The model number will be found on a plate attached to the unit.


Look for this symbol. It means - ATTENTION! BECOME ALERT! A HAZARD TO OPERATOR, BYSTANDERS, PROPERTY OR EQUIPMENT MAY EXIST.

WESTERN INTERNATIONAL INCORPORATED P.O. BOX 377 DES MOINES, IOWA 50302

Part No. 63066

0587

REPAIR PARTS



ALWAYS GIVE THE FOLLOWING INFORMATION WHEN ORDERING REPAIR PARTS:

1. The PART NUMBER; 2. The PART NAME; 3. QUANTITY DESIRED; 4. The MODEL NUMBER (As shown on Model Plate)

SEND PART ORDERS AS PER INSTRUCTIONS ON THE FRONT PAGE

YOUR UNIT IS RIGHT HAND (RH) OR LEFT HAND (LH) AS YOU STAND BEHIND IT.


DO NOT USE KEY NUMBERS WHEN ORDERING REPAIR PARTS, ALWAYS USE PART NUMBERS.
All replacement parts will be supplied in current production colors or in a neutral color.
A handling fee is applicable to small parts orders.

Key	T	T	7	<u> </u>	7	
No.	Part No.	Description	╛	Key No.	Part No.	Description
1	122207	*Screw, Hex Hd, 3/8-16 x 3 In.		50	45602	Washer, 5/16 In.
2	9414074	Locknut, 1/2-13 Thd.		51	120229	*Screw, Hex Hd, 5/16-18 x % In.
3	57167	Bracket, Deck Hanger		52	57220	Screw, Taptite
4	36625	"E" Ring	1	53	54873	Trough, Oil Drain
5	52407	Bearing, Front Spindle		54	Engine	§See Footnote Below
6	55730	Front Axle Assembly		55	173063	Screw, Hex Hd, 5/16-18 x 3½ In.
7	120369	*Nut, Hex, 3/8-24 Thd.		56		Engine Part
8	120382	*Lockwasher, Split, % In.	-	57	57908	Muffler
9	52387	Front Spindle Assembly	ļ	58	46708	Gasket, Muffler
10	41108	Tire, Front	1	59	57259	Belt Guide
11	642	Flatwasher, ¾ In.		60	57315	Belt Guide
12	40394	Hub Cap	1	61	138489	Star Washer
13	39979	Bearing, Front Wheel		62	50947	Screw, Taptite, %-16 x 11/4 In.
14	24167	Valve Stem		63	57211	Switch
15	39829	Wheel w/Bearing, Front		64	56430	Spacer
16	21275	Ball Joint		65	57333	Pulley
17	124925	*Nut, Hex, 3/8-24 Thd.	-	66	56431	Washer, Pilot
18	57194	Steering Link		67	120383	*Lockwasher, Split, 7/16 In.
19	57158	Ball Joint	ł	68	181682	Screw, Hex Hd, 7/16-20 x 4 In.
20	52403	Shoulder Bolt, Front Axle Pivot	-	69	56432	Key
21	122168	*Screw, Hex Hd, 38-16 x 134 In.	ı	70	41890	Shoulder Bolt
22	9413534	Locknut, %-16 Thd.		71	39659	Belt Retainer
23	57151	Tie Rod Assembly	1	72	35374	Pulley, Idler
24	52388	Front Spindle Assembly, R.H.		73	4107	Washer, % In.
25	2483	Spring Washer	l	74	57202	Idler Arm
26	55633	Steering Wheel		75	45892	Carriage Bolt, Rd. Hd, 38-16 x 1½ In.
27	456836	*Roll Pin, ¼ x 2¼ In.		76	57204	Rod, Clutch
28	57212	Cover, Steering Shaft		77	57203	Brake Rod
29	57156	Shaft, Steering		78	56359	Spring, Clutch
30	454565	*Roll Pin, ¼ x 1¼ In.		79	271184	*Keps Nut, 5/16-18 Thd.
31	52428	Pinion, Steering		80	57217	Bracket, Brake Rod
32	52405	Bushing	1	81	20507	Shoulder Bolt
33	22265	Washer, ½ In.	1	82	3021	Key, Woodruff
34	52382	Sector Gear		83	22053	Retaining Ring
35	52406	Eccentric		84	55520	Pulley
36	180177	*Screw, Hex Hd, ½-13 x 1½ In.	1	85	57214	V-Belt
37	55514	Knob, Gear Shift	1	86	54690	Stabilizing Bracket
38	57169	Shift Lever	ĺ	87	120638	*Lockwasher, Split, 5/16 In.
39	57269	Spacer, Transaxle		88	122007	*Screw, Hex Hd, 5/16-18 x 3/4 In.
40	137185	*Pin, Cotter, 1/8 x 1 In.	ı	89	57164	Tire, Rear
41	56348	Shift Bracket	1	90	57165	Wheel, Rear
42	54767	Heat Shield, Muffler		91	39628	Key, 3/16 x 3/16 x 2½ In.
43	120386	*Flatwasher, 5/16 In. I.D.		92	180112	*Screw, Hex Hd, 5/16-18 x 23/4 In.
44	Transaxle	Peerless, 5 speed, Model 900			63037	Operator's Manual (English)
45	42815	Flatwasher, ¾ In. I.D.			63065	Owner's Manual (French)
46	9413447	Locknut, 5/16-18 Thd.			63066	Repair Parts Manual (English)
47	120393	Washer, 11/32 In.			13000	rate manda (English)
48	21682	Washer, ¾ In.				:
49	51579	Washer		l	I	İ
		Items May Ro Burchaged Legally	- 1			· · · · · · · · · · · · · · · · · · ·

^{*}Standard Hardware Items - May Be Purchased Locally.

[†]Contact Tecumseh/Peerless authorized service dealer for parts and warranty.


^{\$}Contact Engine Manufacturer's authorized service dealer (See Engine Manual) for parts and warranty.



Key					
No.	Part No.	Description			
1	57215	Screw, Taptite, 5/16-9 x 3/4 In.			
2	50988	Gauge, Fuel			
3	49050	Screw, Plastite, ¼-20 x ¾ In.			
4	57799	Hood			
5	56303	Edging, Hood			
6	57159	Latch, Hood			
7	8482	Shoulder Bolt			
8	120394	*Flatwasher, 13/32 In.			
9	53446	Pin, Hood Latch			
10	138538	Lockwasher, Int. Tooth, 5/16 In.			
11	54885	Pad, Fuel Tank			
12	48812	Fuel Tank			
13	45174	Locknut, Wide Fl. 5/16-18 Thd.			
14	56045	Dash			
15	271166	*Nut, Keps, No. 10-24 Thd.			
16	50117	Throttle Control			
17	995346	*Screw, Taptite, ¼-20 x ½ In.			
18	41008	Clamp, Fuel Line			
19	57876	Tubing, Fuel Line			
20	41482	Press Clip			
21	35291	Screw, Hex Hd, No. 10-24 x 1/2 In.			
22	70458	Decal, Dash			
23	39486	Knob, Throttle Control			
24	120834	*Screw, Hex Hd, 5/16-18 x 1/2 In.			
25	120638	*Lockwasher, Split, 5/16 In.			
26	20507	Shoulder Bolt			
27	57417	Mounting Bracket, Seat			
28	57500	Seat			
29	44811	Screw, Taptite, ¼-20 x ¾ In.			
30	57153	Spring, Seat			
31	56060	Clip, Seat			
32	57170	Fender Assembly			
33	56907	Cover, Spring			
34	9413447	Locknut, 5/16-18 Thd.			

	Key					
	No.	Part No.	Description			
	35	57152	Bracket, Support			
	36	120228	*Screw, Hex Hd, 5/16-18 x % In.			
	37	122017	*Screw, Hex Hd, 5/16-18 x 1 In.			
	38	446363	*Flatwasher, ¾ In.			
	39	70117	Decal, Caution			
	40	57461	Console			
	41	20864	Retaining Ring			
	42	57213	Spring, Brake Pedal Return			
	43	57196	Rod, Brake-Clutch			
1	44	57820	Food Pad, R.H.			
	45	52785	Pad, Brake Pedal			
	46	52575	Brake Pedal Assembly			
	47	57462	Main Frame			
	48	53402	Grille			
	49	36149	Shoulder Bolt			
	50	57798	Bracket, Grille, R.H.			
	51	57797	Bracket, Grille, L.H.			
	52	55835	Pad, Hood Top			
Į	53	57821	Foot Pad, L.H.			
ı	54	57362	Upstop Bolt			
ı	55	56361	Bracket, Axle Support			
١	56	55836	Pad, Hood Side			
ı	57	55511	Ground Wire			
١	58	43964	Bracket, Deck Guide Support			
	59	120386	*Flatwasher, 5/16 In.			
ı	60	49777	Guide, Rear Deck			
- [61	54806	Spacer			
	62	56030	Screw, Hex Hd, 5/16-18 x 3/4 In.			
-	63	55273	Locknut, Wide Flange, 5/16-18 Thd.			
-1	64	54807	Spring, Return			
	65	57259	Belt Guide			
	66	57569	Retainer, Wire			
I	67	9413534	Locknut, %-16 Thd.			
ł	68	55540	Bulkhead, Dash			


^{34 9413447} Locknut, 5/16-18 Thd.
*Standard Hardware Items - May Be Purchased Locally.



Key			
No.	Part No.	Description	
1	47816	Pin, Clevis	
2	56180	Hairpin Cotter	
3	57340	Pivot Bracket	
4	9413447	Locknut, 5/16-18 Thd.	
5	57196	Pin, Pivot	
6	20864	"E" Ring	
7	57327	Lift Support Plate	
8	120228	*Screw, Hex Hd, 5/16-18 x ⅓ In.	
9	57328	Belt Guard, L.H. Pulley	
10	56424	Quill Assy (Incl. Nos. 11-19)	
11	51445	Locknut, Flange	
12	56365	Flatwasher	
13	56390	Pulley	
14	51449	Spacer	
15	49562	Bearing	
16	. 50818	Spacer, Tube	
17	55547	Quill	
18	50616	Dust Shield	
19	56425	Saddle & Shaft Assy.	
20	121222	*Cotter Pin, 3/32 x ¾ In.	
21	49320	Support, Cable Pulley	
22	49332	Pin, 36 x 1 In.	
23	39298	Pulley, Nylon	
24	57298	V-Belt	
25	35410	Spring	
26	57220	Screw, Taptite	
27	57211	Switch, Deck	
28	120386	*Flatwasher, 5/16 In. I.D.	
29	57764	Wire Assembly, Deck	
30	57325	Carriage Bolt, ¾ - 16 x 2 ln.	
31	52694	Pulley, Idler	
32	121954	*Screw, Hex Hd, ¼ - 20 x 2 ln.	
33	52695	Retainer, Belt	
34	271172	Keps Nut, ¼ - 20 Thd.	
35	57581	Idler Arm Assy. (Incl. Nos. 38 & 39)	
36	9413534	Locknut, ¾ - 16 Thd.	
37	57323	Shoulder Bolt	
38	41601	Rivet, Brake Pad	
39	41471	Brake Pad	
40	996416	*Flatwasher, ¾ In.	

40	996416	*Flatwasher, ¾	ln.
			Purchased Locally.

Key					
No.	Part No.	Description			
41	57316	Spring, Clutch			
42	57326	Clutch Cable			
43	57818	Chute Guard			
44	52456	Retainer, Cable			
45	57322	Shoulder Bolt			
46	57321	Spring			
47	57318	Retainer, Belt			
48	8260	Hairpin Cotter			
49	120396	Flatwasher			
50	57337	Quadrant			
51	57339	Clutch Lever			
52	9424215	Locknut, 1/4 - 20 Thd.			
53	46478	Grip, Clutch Lever			
54	57334	Spring, Discharge Chute			
55	57317	Rod, Pivot			
56	120834	*Screw, Hex Hd, 5/16 - 18 x 1/2 ln.			
57	57360	Bracket, Pivot			
58	70159	Decal, Height Adjust			
59	122040	Screw, Hex Hd, 5/16 - 18 x 1½ In.			
60	57314	Skid Bar			
61	271184	*Keps Nut, 5/16 - 18 Thd.			
62	126216	*Carriage Bolt, 5/16 - 18 x ¾ In.			
63	56924	Grip, Height Adjust Lever			
64	57329	Height Adjust Lever			
65	57324	Screw, Latch			
66	995346	Screw, Taptite, ¼ - 20 x ½ In.			
67	57319	Spring			
68	52584	Wheel, Deck			
69	23763	Wheel Axle			
70	5 7338 -	Pivot Tube Assy. 310 とる			
71	120372	*Nut, Square, ¼ - 20 Thd.			
72	57313	Lift Cable			
73	39404	Clevis, Lift Cable			
74	39522	Pin, Clevis			
75	51985	Support, Pivot Tube			
76	57045	Mower Deck			
77	50634	Screw, Taptite, 5/16 - 18 x % In.			
78	57299	Blade			
79	2483	Formed Washer			
80	39573	Screw, Hex Hd, %-24 x 1 In.			
81	68547	Decal, Caution			



Key No.	Part No.	Description		Key No.	Part No.	Description
1	39463 49643	Ammeter Key, Ignition		18 19	138485 187745	*Washer, Ext., Shakeproof, 5/16 In. *Screw, Hex Hd, ¼-20 x ¾ In.
3	48140	Locknut (Switch part)		20	9424215	Locknut, Hex, ¼-20 Thd.
4	138557	Lockwasher (Switch Part)		21 22	53716	Solenoid Engine Part
5 6	52583 49211	Switch, Ignition w/Keys Fuse		23	54888	Retainer, Wire
7	57625	Wire Harness Assembly		24	41482	Wire Clip, Press
8	57552	Battery Rod		25 26	56189 50668	Lead Wire, Headlight Screw, Hex Wa. Hd, No. 10-14 x ½ In.
9 10	57551 271172	Bracket, Battery, Hold-Down *Nut, Keps, ¼-20 Thd.		27	52572	Bulb, Headlight
11	55511	Ground Wire		28	52571	Bezel, Headlight
12 13	52936	Battery *Carriage Bolt, ¼-20 x % In.		29 30	52570 126216	Lens, Headlight Carriage Bolt, 5/16-18 x ¾ In.
14	126203 120392	Flatwasher, ¼ In.	ł	31	271184	Nut, Keps, 5/16-18 Thd.
15	120380	Lockwasher, Split	ļ	32	57764	Wire Assembly, Deck
16 17	120375 120368	*Nut, Hex, ¼-20 Thd. *Nut, Hex, 5/16-24 Thd.				

^{*}Standard Hardware Items - May Be Purchased Locally.